

# Model J744 Optical-Electrical Converter



**Technical Manual** 

June 15, 2023

Copyright © Highland Technology 650 Potrero Avenue, San Francisco, CA 94110 Phone 415-551-1700 • Fax 415-551-5129 www.highlandtechnology.com

#### NOTICE

HIGHLAND TECHNOLOGY, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

(Disclaimer of expressed or implied warranties in certain transactions is not allowed in some states. Therefore, the above statement may not apply to you.)

This manual may contain technical inaccuracies and/or typographical errors. Changes are periodically made to this manual, which are incorporated in later editions. Highland Technology, Inc. may make changes and improvements to the product(s) and/or programs described in this publication at any time without notice.

This product has finite failure rates associated with its hardware, firmware, design, and documentation. Do not use the product in applications where a failure or defect in the instrument may result in injury, loss of life, or property damage.

IN NO EVENT WILL HIGHLAND TECHNOLOGY, INC. BE LIABLE FOR DAMAGES, INCLUDING LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE SUCH PRODUCT, EVEN IF HIGHLAND TECHNOLOGY, INC. OR AN APPROVED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

## Contents

1	Introduction	4
	Specifications	
	Overview	
4	Waveforms	8
5	Versions	9
6	Customization	9
7	Hardware Revision History	9
8	Accessories	9

# 1 Introduction

This is the technical manual for the Highland Model J744 compact analog optical-toelectrical converter.

## Features of the J744 include:

- ST or FC fiberoptic input
- DC coupled, 1 GHz analog bandwidth
- Nominal 1 V / mW gain
- Two available wavelength ranges
- Compact 2.5" x 3.3" enclosure



# 2 Specifications

FUNCTION	DC-coupled analog optical-electrical converter				
INPUT	850 nm versions accept 62.5/125 μm multimode fiber 1310/1550nm versions accept 9/125 μm singlemode fiber Optional ST or FC connectors Linear from 0 to 2 mW optical input				
OPTICAL WAVELENGTH	GaAs version: 700- 875 nm InGaAs version: 1100 - 1650 nm				
PROPAGATION DELAY	Light in to electrical out < 850 ps				
	DC coupled, SMA connector				
OUTPUT	50 ohm source impedance				
	1 V/mW nominal sensitivity at peak wavelength, Hi-Z load 0.5 V/mW nom into 50 ohms				
BANDWIDTH	DC to > 1GHz				
RISETIME	< 350 ps				
JITTER	< 12 ps RMS, J720 + J744				
OPERATING TEMPERATURE	0 to 60°C				
CALIBRATION INTERVAL	1 year				
POWER IN	+12 VDC, 135mA nominal. J12 wall-plug universal-input power supply included				
CONNECTORS	ST or FC optical input receptacles Gold plated SMA analog output jack 2.1mm X 5.5mm barrel power connector				
INDICATOR	LED: Green power				
PACKAGING	Aluminum enclosure, 3.3" (L) x 2.5" (W) x 1.0" (H) J732 mounting flange included				

## 3 Overview

The J744 includes a fast fiber-coupled photodiode, a transimpedance amplifier, an output amplifier, and power supplies.

Output is nominally 1 volt per milliwatt of optical input when driving a high impedance load, such as a hi-Z oscilloscope. Output is 0.5 V/mW into a 50 ohm load.

Bandwidth will be limited when driving a hi-impedance oscilloscope by the scope's typical input capacitance. Full bandwidth requires that the J744 drive a very fast 50 ohm scope through a short, low-loss 50 ohm coaxial cable.

Two versions are available with peak wavelength response at 850 or 1500 nm.

The J744-1 and -11 versions use a GaAs photodiode and are typically used with 850 nm sources.

Please refer to

Figure 1 below for the GaAs photodiode's nominal wavelength curve:

# Wavelength vs Responsivity




Figure 1: 850 nm GaAs detector typical response

The J744-3 and -13 versions use an InGaAs photodiode and are typically used with 1310 and 1550 nm sources. Please refer to Figure 2 below for the InGaAs photodiode's nominal wavelength curve:




Figure 2: 1310/1550 nm InGaAs detector typical response

## 4 Waveforms

Figure 3 and Figure 4 below show typical O/E performance, showing both optical and electrical signals. Optical signals were produced using an 850nm multimode10Gb/s SFP module for GaAs versions. A 1310nm singlemode 10Gb/s SFP was used for InGaAs versions. The reference photodetector was a Tektronix SD-43 8GHz O/E. All electrical signals were resolved using a Tektronix SD-24 20GHz sampling head and 11801B scope.




Figure 3: J744-1 and -11 GaAs versions with 850nm optical source at 400MHz and 1GHz




Figure 4: J744-3 and -13 InGaAs versions with 1310nm optical source at 400MHz and 1GHz

## 5 Versions

Standard versions of the J744 include:

Model	Part Number	Nom Wavelength	Fiber Connector	Photodiode
J744-1	21A744-1	850nm	ST	CaAa
J744-11	21A744-11		FC	GaAs
J744-3	21A744-3	1310nm/1550nm	ST	In Co A o
J744-13	21A744-13		FC	InGaAs

## 6 Customization

Consult factory for information about additional custom versions.

## 7 Hardware Revision History

Revision A January 2020 Initial PCB release

## 8 Accessories

J12-1: 12 volt power supply (included with purchase)

J44-1: 3' SMA to SMA cable

J59-1: 3' ST to ST fiberoptic cable (multi mode simplex)

J60-1: 3' FC to FC fiberoptic cable (single mode simplex)

J61-1: 3' ST to ST fiberoptic cable (single mode simplex)

J732-1: mounting flange (included with purchase)